



Notes:

1. Populate C2 with a 1000uF for long time periods or populate it with a 100uF for shorter time periods. If you need longer times, you may populate C4 with another Capacitor. This will give you longer delays.
2. Trigger input should be a switch.

NightFire Electronics		
Timer with Relay 1		
www.vakits.com		