



**Notes:**

The LEDs will both flash when there is no transistor. A good PNP Transistor will cause the RED LED to remain on while a good NPN will cause the Green LED to remain on. A shorted transistor (Collector-Emitter) will cause both LEDs to turn off.

PWR should be 12v or higher for good operation.

NightFire Electronics		
Transistor Tester		
<a href="http://www.vakits.com">www.vakits.com</a>		