



Notes:  
 Populate only what you need.  
 Add Jumper1 for ASTABLE operation.  
 VCC may be as low as 6v, typical is 12v.  
 Q1 may be TO-92 or TO-220.  
 Values are typical.

NightFire Electronics		
#1710	LM555 Development PCB www.vakits.com	Rev A