



Notes:

The LEDs will both flash when there is no transistor. A good PNP Transistor will cause the RED LED to remain on while a good NPN will cause the Green LED to remain on. A shorted transistor (Collector-Emitter) will cause both LEDs to turn off.

PWR should be 12v or higher for good operation.

NightFire Electronics		
	Transistor Tester www.vakits.com	Rev A