



Notes:
 For single supply voltage, jumper -V to GND.
 Pin 8 is not connected.

Use with:
 LM741
 LF351
 TL061
 TL071

NightFire Electronics		
	Op Amp DEVELOPMENT PCB	Rev A